

# XFW - EXTRA FOREFOOT WEDGE

MR1600



NEUTRAL FOOT STATUS



SUPINATION



PRONATION

**XFW STANDS FOR EXTRA FOREFOOT WEDGE** This wedge can be used together with the MediRoyal MOW® and LOW®-insoles to increase the lateral/medial correction. The wedge is 6 mm and made of high density EVA. It can be used either lateral or medial to correct the forefoot. It can be fixated by the enclosed self-adhesive tape or glued permanently in place by using contact glue. Sold in 1 pair.

MR1600 XFW EXTRA FOREFOOT WEDGE

Universal size 34-47



mediroyal 

Mediroyal Nordic AB  
Box 7052, 192 07 Sollentuna, Sweden  
Visiting address: Staffans väg 6B, Sollentuna  
Tel +46 8 506 766 00 Fax: +46 8 506 766 90

[www.mediroyal.se](http://www.mediroyal.se)  
[info@mediroyal.se](mailto:info@mediroyal.se)  
[facebook.com/MediroyalNordic](https://facebook.com/MediroyalNordic)